


AUTOBALER

OPERATION MANUAL


TI100/TI200 SERIES



www.autobaler.com

Trethewey Industries

14 Carl Baer Circuit
New England Highway
Deepwater NSW 2371
Australia



Owners Manual

Thank you for choosing Autobaler TI100/TI200. It is our wish that you remain very happy with the performance and service given by your baler and our service backup staff.

For operating this baler properly, please take time to read this manual thoroughly before start to operate your baler.

Keep this manual handy for future reference.

The information contained in this manual is basic information. If you require information over and above what is supplied in this manual, please contact the Autobaler service hotline on 1800 888 403.

Models covered by this manual

TI100/TI200 Autobaler

Note

Training is required to operate Autobalers.

Training is required to service Autobalers.

Autobalers are protected by International Patents and Patent Applications.

OPERATION AND MAINTENANCE MANUAL

USER MANUAL

SPECIFICATION MANUAL

MACHINE - AUTOBALER and CYBERSMART CONTROLLER

MODEL - TI100/TI200

AUTOBALER SERIAL NUMBER - _____

CONTROLLER SERIAL NUMBER - _____

Name and Address of Manufacturer

Trethewey Industries
14 Carl Baer Circuit
Deepwater NSW 2371
Australia

Please Read This Document BEFORE Operating the Machinery

WARRANTY

To maintain warranty the baler must be serviced in accordance with the manufacturers recommendations outlined in chapter 9 and the service booklet.

The firm guarantees the machine hereby described has been designed in compliance with all regulations in force, in particular safety and health regulations. The machine has undergone successful testing. (See test certificate enclosed.)

The warranty covers a period of 12 months. It does not cover electrical motors and tools. Extended warranty to 5 years is available

The purchaser is entitled to the replacement of faulty parts. Shipping and packing costs are at the purchaser's expense.

The warranty does not cover damage caused by: Falls or careless handling of the machine, incorrect operation, and non-compliance with the maintenance rules. **Any tampering with the machine, especially with its safety devices, automatically voids warranty.** The manufacturer will be freed from any responsibility.

No claim for damages shall be accepted in cases where the machine has been laying idle for a long period of time.

The serial number on the machine is a main reference for the warranty, instructions manual and after sales service and identifies the machine in case of need.

Serial Number must be quoted in all correspondence.

NOTES

The machines are manufactured in compliance with the accident prevention rules in force.

The machines strictly comply with the instructions contained in the manual to obtain the best performance from the machines. Strict compliance with the rules contained will ensure optimum results and avoid any inconvenience caused by the non-compliance of operation and maintenance instructions.

To avoid contacting the manufacturer for problems which can be easily solved, closely follow the instructions given below.

If the help of our technical assistance service is still required after having strictly complied with the instructions given, the buyer must supply all the technical indications necessary to effectively determine the problem. This will enable our technical assistance service to intervene quickly and efficiently on the machine. Copies of the instructions manual may be requested upon indication of the machine serial number.

IMPORTANT

Upon delivery of the machine, the consumer must make sure that all the devices indicated in the paragraph on the safety manual are present and working correctly. Furthermore, those devices which are not mounted at the time of delivery to facilitate transport must be mounted in conformity with the instructions indicated.

When ordering spare parts it is necessary to state:

- Machine Model
- Serial Number and Year of Manufacture
- Item Reference Number

Without the Serial Number, no spare parts will be delivered!

DEFINITIONS

INDEX

Warranty	5
Scope	7
Manufacturing Plate	7
Declaration of Conformity	8
Compliance	9
Baler Test Report	10-14
Hazard Identification	15
Installation of Overhead Safety Canopy	16
Chapter 1	
Warnings	17
Copy of Warning Notices	17
Chapter 2 - Lifting & Handling Instructions	
Specifications	18
Transporting the Autobaler Safely	18
Baler Relocation Procedure	18
Removing the baler from the pallet	18
Locating from truck to dock	18
Work Method Statement	19
Chapter 3 – Safety	
Location of Autobaler	20
Area of Operation	20
Operation of Autobaler	20
Safety Clothing / Footwear	20
Safety Essentials	21
Chapter 4 – Operation of Autobaler	
Bale removal procedure	22
Twining up the TI100/TI200	23-25
Controller layout and function	26-27
Chapter 5 – Training	
Trainer Material	28-43
Trainee Particulars Kit	44-46
Chapter 6 – Maintenance & Cleaning Section	
Maintenance Definition	47
Weekly maintenance Check	47
Preventative Maintenance	47
Machine Cleaning	47
General Housekeeping	47
Service Intervals	47
Recommended Lubricants	48
Data Sheet - Pro-ma MBL8 Grease	48-49
Material Safety Data Sheet – Super-hydraulic	50-51
Chapter 7 – Drawings	52-53

SCOPE

Background

Autobalers are a unique compacting machine featuring an open top system to facilitate loading of the baler with materials. Autobalers offer considerable time savings when compared with most other baler types. The time to compact is reduced on account of no doors to open and close each time materials are deposited. The Autobaler can be loaded during any part of its cycle path.

Autobalers are a safe machine reducing many of the common injuries associated with conventional balers such as strain injuries from pushing and forcing of materials into fixed sized areas. Many injuries also occur due to material breakdown with knives and other injury creating devices. AUTOBALER REQUIRES NO MATERIAL BREAKDOWN.

Autobalers are an extremely versatile machine being able to compact a large range of materials i.e.: paper, cardboard, plastics, rubber tyres, wool and most otherwise compactable materials. Autobalers come in a ten model capacity range from 80 to 500+ kg to best suit particular customer requirements. Autobalers are a quality machine offering unparalleled safety, amazing efficiency and huge labour savings.

Trethewey Industries have vast experience in the manufacture of quality baling machines, having produced in excess of 500 agricultural baling machines. Five years ago Trethewey's developed the Autobaler for commercial use, in particular to be used in Supermarkets and Recyclers. Trethewey Industries are situated on the New England Hwy at Deepwater NSW. Trethewey Industries location is ideal for servicing our national markets. Trethewey Industries focus is to develop machines which totally satisfy customer requirements in performance, quality, service, economy and safety.

Autobalers were developed to give the maximum efficiency and safety possible. Autobalers are designed for loose materials and are not recommended for solid materials (i.e. hard wooden or metallic objects) as these may cause machine damage. The manufacturers are happy to assess your needs and make recommendations and give assurances on the type of baler which will best suit your requirements.

Autobalers are built to comply with the highest national and international standards.

Autobalers are protected by International Patents and Patent Applications.

Manufacturing Plate:

TRETHEWEY INDUSTRIES Pty Ltd A.B.N. 84 072 739 827	
<i>Innovative Design & Manufacturing</i>	
	New England Highway DEEPWATER NSW 2371
Tel: 02 6734 5403 Fax: 02 6734 5433	
EMAIL: trethewey@northnet.com.au	
WEBSITE: www.autobaler.com	
+ PATENT No's +	
AU99 PCT 000 48	AUPR 8089
AUPR 8445	AUPR 3941
AUPR 4116	AUPR 8930
MODEL:	
S/N:	
BATCH No:	
RATED VOLTAGE:	
NUMBER OF PHASES:	
FREQUENCY:	
FULL LOAD CURRENT: AMPS-	
Date of Manufacture:	

DECLARATION OF CONFORMITY

98/37/EC Machinery Directive
73/23/EEC Low Voltage Directive
89/336/EEC EMC Directive

Name of manufacturer or supplier

Trethewey Industries Pty Ltd

Full postal address including country of origin

14 Carl Baer Circuit, Deepwater, NSW 2371, Australia

Description of product

Paper & Cardboard Baling Machine

Name, type or model, batch or serial number

Type - Autobaler

Make - Trethewey Industries Pty Ltd

Model – TI100/TI200

Location – 14 Carl Baer Circuit, Deepwater, NSW 2371 Australia

Supply - 415V ac 3 -

Serial No: _____

Mass Weight - _____

Standards used, including number, title, issue date and other relative documents

See attached sheets

Place of issue

Address of Authorised representative in Europe

Name of authorised representative: _____

Position of authorised representative: _____

Full postal address if different from manufacturers

Address of Authorised Representative in Europe

Declaration

I declare that as the authorised representative, the above information in relation to the supply / manufacture of this product is in conformity with the stated standards and other related documents following the provisions of the above Directives and their amendments.

Signature of authorised representative _____ Date _____

Trethewey Industries

Autobaler

Trethewey Industries Pty Ltd

14 Carl Baer Circuit

Deepwater

NSW. 2371

14 November 2003

**ASSESSMENT REPORT
AUTOBALER
FOR COMPLIANCE WITH MACHINERY
DIRECTIVE 98/37/EC**

**THIS REPORT IS PREPARED BY RISKPLANT CONSULTANTS PTY LTD FOR RISK
MANAGEMENT PURPOSES, AND ITS CONTENTS ARE PROVIDED EXPRESSLY FOR THE
NAMED CLIENT FOR ITS OWN USE**

**NO RESPONSIBILITY IS ACCEPTED FOR THE USE OF, OR RELIANCE UPON THIS REPORT,
IN WHOLE OR IN PART, BY ANY THIRD PARTY.**

**Prepared by
Roger Lim, MIE Aust, CPEng, MSIA
RiskPlant Consultants Pty Ltd
(ABN 78 086 256 206)**

**PO Box 115
BLACKBURN NORTH VIC 3130
Ph: (03) 9877 4519
Fax: (03) 9877 4569**

**NATA Accredited (No. 14155)
Machinery Safety
Inspection Services**

Baler Test Report

Comprehensive Autobaler Test Report

Date:

Serial No:

Testing Officer:

Electrical Test Performed By:

Noise Emission Test:

Hydraulic Test:

Autobaler Quality and Reliability Test - Full Mechanical Test

Test Report No:

Testing Officer:

Operational Test Report No:

Testing Officer:

Lubrication Test Report No:

Testing Officer:

Testing Officer:

Signature:

Hydraulic Pressure and Performance Test

“Report on Safety and Hydraulic Performance”

This report is suitable for pressure systems below 2500 psi.

System Pressure Required:

System Pressure on Test:

System Pressure Spikes:

Pressure Switch Firing Range:

Pressure Switch Firing Test:

Hydraulic Delivery Hose Rating:

Fluid Type and Grade:

Cylinder Brand and Type:

Duration of Cycle Test:

Date:

Inspector:

Signature:

Noise Emission Test Report

Baler Noise Emission report - the test done from five positions:-

- a. From each side at a distance of 1m from the machine
- b. At a distance of 1m above the machine

Decibel monitor type and number:

Test one metre from front:

Test one metre from left side:

Test one metre from right side:

Test one metre from back:

Test one metre above machine:

Injury precautions required:

Date of Inspection:

Inspection No:

Inspector:

Signed:

Earth Bonding and Electrical Test

Report on Safety Inspection and Testing of Electrical Equipment

This report is suitable for class 1 protectively earthed 3 phase 415V equipment. The test has been carried out in accordance with AS/NZS 3760, with the following electrical and visual inspections:

500V Insulation Resistance Tests

- Active 1 to earth: Pass Fail
 - Active 2 to earth: Pass Fail
 - Active 3 to earth: Pass Fail
- Earthing continuity: Pass Fail

Flexible supply cord:-

- External visual inspection of plug connection: Pass Fail
- Visual inspection of cord termination to equipment: Pass Fail

Visual inspection of wire termination in electric motor terminal housing: Pass Fail

Date:

Inspection number:

Inspector:

Inspector registration number:

Signed:.....

Trethewey Industries

New Machinery Hazard Identification assessment and Control

Description: Autobaler

Model: TI100/TI200

Brand:

Developed in Co-operation Between AWISA and Australia Chamber of Manufactures.
This program is based upon the Australian Worksafe Standard for Plant NOHSC:1010-1994

Item No.	Hazard Identification	Hazard Assessment	Risk control Strategies
A	Entanglement	Very Low	Do not reach into baler. Operator Training
C	Cutting, stabbing, puncturing	Very Low	Use only safety knife for bale tie off.
D	Shearing	Nil	
E	High Temperature	Nil	
F	Striking	Moderate	Upper or lower door rebound. Operator Training
G	Crushing	Low	Bale ejection. Operator Training
H	Electrical	Low	Operator Training
O	Other hazards, noise dust.	Moderate noise	Noise if operated with insufficient materials in hopper. Operator training

Installation Instructions for the Overhead Safety Canopy

FITTING OF THE OVERHEAD FRAME

- From within the baler lift frame – the rear support legs will telescope out
- When the holes in the telescoping rear legs appear, slide in retaining bolts to hold the frame in position. This operation may require two people or the use of a fork lift or mechanical lifting device.
- Firm up the grub screws on these legs
- Fit the mesh sections supplied – these will only fit one way.
- Tighten up the grub screws in the saddles to secure the mesh tabs to the baler
- The mesh frames should be now securely attached to the baler frame
- Firm up grub screws on baler saddles locking overhead frame into position. Note: mesh hopper must be on the inside of the legs (see illustration 2)
- Frame should now be as the picture below,

If you require further information on the fitting procedure, please contact the manufacturers on:-
1800 888 403 or 02 67 345403

FITTING OF THE SAFETY CANOPY:



Fitted Overhead Safety Canopy.



Rear Canopy legs position



Mesh mounting lugs

CHAPTER 1
Warnings

1. Autobalers must only be operated by qualified people.
2. Only qualified people to service or repair Autobalers.
3. Before servicing or repair familiarise yourself with the relevant instruction manual.
4. The Autobaler must not be used in a manner contrary to the manufacturer's instructions.
5. Prior to moving the Autobaler ensure the fork lift capacity is at least 1.5 tonne.
6. On installation or repair ensure the machine is effectively earthed. (All electrical work to be carried out by qualified electrician).
7. Always disconnect the electrical supply before servicing or repair due to electrical hazard.

Failure to observe Safety Precautions could lead to severe injury.

We recommend operators using the following personal protective equipment:-

1. Safety glasses
2. Safety shoes
3. Safety gloves

COPY OF WARNING NOTICES ON MACHINE
(INCLUDING NAMEPLATE)

"AUTOBALER SAFETY INSTRUCTIONS"
READ INSTALLATION MANUAL BEFORE USE

1. **ALWAYS** locate the Autobaler away from elevated areas to prevent unsafe access to the baler chamber. (e loading docks etc)
2. **NEVER** alter change is required, always call an electrician.
3. **CHILDREN** must be kept away from the Autobaler at all times.
4. **DO NOT** reach or lean into the Autobaler during operation.
5. **DO NOT** touch the twine cage and bale tray as to prevent injury due to tripping.
6. **BEFORE** opening the top door beware of possible handle rebounds.
7. **BEFORE** opening the bottom door 1. Stand to the side, 2. Beware of possible door rebounds.
8. **NEVER** attempt to enter the Autobaler for 1. Rewinding, 2. Side tie off, 3. Tying or for any reason without stopping the baler via the key switch or stop button, then the door can be opened.
9. **NEVER** operate the Autobaler unless qualified to do so. See OHS officer for training details and training procedures or contact the Autobaler supplier or manufacturers
10. **NEVER** manually handle the bales, use bale transport trolley provided.
11. **ALWAYS** remove key from unattended Autobaler.

TRETHEWEY INDUSTRIES AUTOBALER
"FACTORS FOR EFFICIENT OPERATION OF THE AUTOBALER"

1. **FREE MATERIALS ONLY**
2. **NO** TIMBER OR HARD OBJECTS
3. **NO** COMPRESSED SLABS OR BALES
4. **NO** BOXES CONTAINING HARD OBJECTS
5. **DO NOT** CYCLE AUTOBALER WITHOUT MATERIALS IN THE HOPPER
6. **IDEALLY**, PLACE FLATTENED CARDBOARD FLAT INTO THE HOPPER
7. **DO NOT** OPEN THE BOTTOM DOOR UNTIL:
 - A. THE BALE IS TIED OFF
 - B. THE FINGERS ARE IN RETRACT POSITION
8. **READ** THE OPERATION AND INSTALLATION MANUAL CAREFULLY BEFORE USE

NOTICE

OPERATIONAL AND INSTALLATION MANUAL INSIDE

YOU MUST READ OPERATION AND INSTALLATION MANUAL BEFORE USE OF THIS AUTOBALER

CAUTION
TURN KEY OFF
BEFORE ENTERING BALER

BEWARE
DOOR REBOUND
STAND TO SIDE

BEWARE
HANDLE REBOUND
(NEVER PUBLIC)



UNAUTHORISED PERSONS MUST NOT OPERATE AUTOBALER

REFER TO OPERATING MANUAL BEFORE MOVING THE BALER OR REMOVAL OFF THE PALLET

NOTICE

ENSURE YOUR TWINE COMPLIES WITH OHS REGULATIONS FOR YOUR TWINE REQUIREMENTS
PHONE 1 900 838 403

CAUTION
DO NOT CLIMB ON BALER

DO NOT OPEN
410V INSIDE

IMPORTANT SERVICE NOTICE

PLEASE CONSULT THE MANUFACTURER'S WEBSITE FOR SERVICE PROCEDURES

FOR THE SERVICE LIFE OF THE MACHINE
CONTACT THE SERVICE REPRESENTATIVE
FOR THE SERVICE PROCEDURES
FOR THE SERVICE LIFE

PHONE: 1 900 838 403

WARNING

THIS EQUIPMENT STARTS AND STOPS AUTOMATICALLY

AUTOBALER

www.autobaler.com
CUSTOMER SERVICE NUMBER
1 900 838 403

CHAPTER 2
LIFTING AND HANDLING INSTRUCTIONS OF THE AUTOBALER

TI100 Specifications	
Bale Weights	100-140kgs
Bale Size	750 x 750 x 1000
Cycle Time	23 seconds
Unit Weight	1250kg
Thrust Load	5350kg
Power	3Kw 3 phase
Plug required	4pin Clipsal compatible
Height	2500mm
Width	1940mm
Depth	920mm
Transport Height	2050mm
Baler Capacity	2-3 bales per hour

TI200 Specifications	
Bale Weights	175-200kgs
Bale Size	750 x 750 x 1000 (mm)
Cycle Time	23 seconds
Unit Weight	1650kg
Thrust Load	10160kg
Power	3Kw 3 phase 20amp
Plug Required	4pin Clipsal compatible
Height	2500mm
Width	1940mm
Depth	920mm
Transport height	2050mm
Baler Capacity	2-3 bales per hour



TRANSPORTING THE AUTOBALER SAFELY

When moving or relocating the baler always follow the Work Method Statement, in most cases it will be a requirement of the organization that the Work Method Statement be completed signed and handed in to the appropriate person or persons for approval before carrying out the task. The following procedure is for the safe transportation and movement of the Autobaler

1. BALER RELOCATION PROCEDURE

1. Before removing or lifting the baler ensure that the lifting equipment is in good order and has capacity to lift the baler – check baler weight in baler specifications.
2. Autobalers balers can be moved with a forklift unit or a pallet truck
3. Before moving the baler ensure that there is sufficient clearance (height wise)
4. Where possible attach the baler to the moving means to prevent possible overbalance
5. Where required situate traffic cones and safety barriers
6. Always transport baler units as close to the ground level as possible – if forward movement is required always used another qualified person as a

guide

7. Proceed slowly – downhill grade always in reverse

2. REMOVING THE AUTOBALER FROM THE PALLET

- a. Unwrap and cut metal strapping
- b. Insert the fork lift tines beneath the front lower door. Ensure that the fork lift tines are fully through to the rear baler wall.
- c. Lift the baler no more than 80mm off the pallet & check again to ensure sufficient tine protrusion through the rear slots
- d. With tines under the baler always move:-
 - as close as possible to the floor
 - at idle speed only
 - in reverse to ensure good vision

Note: When transporting the Autobaler where lifting on a truck is required

- a. Never lift the baler more than 300mm unless on a pallet or strapped securely to the fork lift, as the baler could slip off the tines (metal to metal)
- b. If lifting the baler from beneath the baler base, fasten the baler to the fork mask using strap or chain
- c. When lifting the baler more than 300mm, always be on level ground and never transport the baler in an elevated position
- d. When transporting or moving the baler on the fork lift, always travel in reverse to ensure good vision
- e. **Safety Equipment: Compliant safety boots, high visibility vest, hearing protection, eye protection. Head protection if required.**

3.LOCATING FROM TRUCK TO DOCK.

When loading the baler for its final destination, the baler is to be loaded in such a way as to facilitate removal at the customer end.

ie. If the baler is to be unloaded using a forklift truck, baler should be situated accordingly.

NB: if baler is to be unloaded via pallet jack, then the pallet containing the baler needs to be rotated through 90 degrees.

Work Method Statement

Activity		Contractor	
Person completing this statement		Telephone	
Date		Contract Number	

Key Steps	Equipment or plant required	Possible Hazards	Safety controls including personal protective equipment (PPE)	Licenses, qualifications or work permits
1.				
2.				
3.				
4.				
5.				
6.				
7.				
8.				
9.				

CHAPTER 3
SAFETY

A. Location of Autobaler:

- a. Never place the Autobaler near any landings or elevated loading docks, unless these areas have the appropriate safety arrangements and approvals.
- b. Never place the Autobaler under a man hole, air conditioner, refrigeration unit, light or any position where a service technician may have occasion to work above the machine.
- c. Never place the Autobaler on a loading dock, close to the edge or the above landings edge.
- d. Never place the Autobaler in a position where unauthorised persons have access.
- e. Always consult an OH&S officer.

B. Area of Operation:

- a. Ensure that baler trolley is stored in a position away from the operator's passageway.
- b. Ensure that twine rolls & twine safety cage are positioned close to the right hand side of the Autobaler to prevent tripping. If cage is provided with hooks, use these to affix cage to safety barrier.
- c. Ensure that electric lead is not in a hazardous position and is not left lying on the floor, particularly if there is a chance of water being on the floor.

C. Operation of Autobaler:

- a. Always keep hands and arms out of the Autobaler hopper during operation.
- b. Always, when entering the pressing chamber for re-stringing etc, wait until the motor stops and turn the key to the "Off" position.
- c. Never attempt to load heavy objects over the top door during the baling process, (reduce boxes of books, brochures etc to smaller quantities).
- d. When removing full bales from the Autobaler, always use the Auto-eject or eject trolley
- e. When ejecting full bales, never pull on the twine in such a manner that if the twine breaks, or the knot fails, a fall will result which may cause an injury.
- f. Always use the baler trolley, pallet jack or fork lift to relocate full bales.
- g. Always be aware of door rebound when opening top or bottom doors, always stand to the side.
- h. Never stand in front of the pressing chamber when ejecting full bales, always stand to the side, eject models only.
- i. Never attempt to operate Autobaler with the front door open.
- j. Never attempt to clean, lubricate or work in the vicinity of the cylinders during operation.

SAFETY CLOTHING / FOOTWEAR

- a. During assembly, location and operation of the baler, safety compliant footwear must be worn.
- b. Firm fitting work place compliant clothing must be worn.
- c. Safety compliant work place gloves, hearing protection and eye protection must be worn.
- d. General

Always remove Autobaler key when machine is not in operation, or is unattended.

SAFETY ESSENTIALS

1. Before commencing the baling process ensure that the bottom door is latched correctly to prevent the door bursting open during process.
2. Never climb onto the baler from any side or reach in during operation or stand on elevated objects.
3. When removing the bale, grip the handle of the eject trolley firmly and pull back with care.
4. Always place the bale transport trolley centrally and in the floor channels to prevent bale side roll.
5. On inclines, take care to prevent run away and potential injury to others.
6. Use only the safety knife for twine cutting.
7. To prevent strain injury ensure that the doors and latches open freely – lubrication may be required
8. Remove baler key if in a safety sensitive zone.
9. Never operate a faulty machine tag out and call 1800 888 403
10. Autobaler operators must be licenced to legally operate Autobalers
11. Note smaller framed people or people of low strength and fitness can sustain injuries from over exertion with bale removal and location – ensure tat the operator is of sufficient strength and fitness to safely perform this task.

CHAPTER 4
OPERATION OF AUTOBALER

BALE REMOVAL PROCEDURE

Larger Autobaler are equipped with auto ejection systems the small 100 series have manual bale removal system

Removal of the Bale

Step 1.

Before commencing the baling especially with smaller granulated materials place a sheet of cardboard on the bottom of the baler to prevent clogging of the baler floor grooves.

Step 2.

Fully open both upper and lower baler doors using the bale extraction trolley supplied with the machine. Insert the trolley tines into the baler lots.

Step 3.

With the trolley forks fully inserted, grip the top of the trolley handle firmly and pull back, carefully drawing the bale from the chamber. (note for ease for extraction the bottom door of the baler must be fully opened.)

Step 4.

With the bale extracted from the baler the bale can be wheeled away and stored.

Safety

Those responsible for the safe operation of the baler must:

1. Ensure that the persons removing the bale have been sufficiently trained in the safest removal procedure.
2. Must be of sufficient strength and fitness to safely carry out this task.
3. Bale trolley storage to prevent a tripping hazard – store the bale trolley with the forks beneath the left hand side and the trolley against the baler.



TWINING UP THE T1100/TI200

The following procedure is for the twining of the T1100/TI200 Autobaler.

Step 1.

Place the roll of twine under the left hand side of the baler. The roll must be the correct side up. The draw end of the twine feeds from the entire of the roll from the top side. Twine type must comply with OH&S requirements (recommended twine type is Superlash8)

Step 2.

From the drawn end lay the twine back approximately 200mm as shown




Step 3.

Tie a knot in the end to form a non-slip loop as per illustration.



Step 4.

In some instances a double know may be required as shown. The reason for this will be explained in a later step.



Step 5.

Hook the looped twine end on the baler tab as per illustration 5 and take the twine to the opposite side as per illustration 6 then bring the twine back to left hand side as illustrated and cut off at this pint using the safety knife supplied illustration 7. This will give the correct length of twine required – Repeat this process three times to give the required amount to twine up the machine.



Illustration 5



Illustration 6



Illustration 7

Step 6.

Fully open all doors and step into the baler chamber (note before entering the baler turn the baler key to the off position) Hook the twine loop over the domed hook as illustrated on the left hand side.




Step 7.

Take the twine down under the tab on the left side on the bottom then across and under the tab on the right hand side then up to the domed hook on the right hand side.



Step 8.

To attach the twine end to the domed hook on the right hand side rotate the twine end around the domed hook twice then tie off using one tie off loom only. Repeat this procedure on both side twines.



Step 9.

Transverse twine (from rear to top)

1. Hook twine loop onto the domed hook on the rear inside wall of the baler.
2. Place the twine under the tabs on the floor (near to front as illustrated).
3. Holding the twine end in the left hand close the bottom door using the right hand.
4. Twine will then come up the inside of the lower door over the top and attach to twine tab as in step 10.




Step 10.

Twine end will come over the top of the bottom door and attach to twine tab by rotating the twine around the twine tab twice then inserting twine into tab slot as illustrated.



CONTROLLER LAYOUT AND FUNCTION



Controller


Almost the total function of your Autobaler is via the Cybasmart control unit. The various functions of the controller are as follows:

1. **Isolating Switch** - The isolating switch is situated on the upper end of the controller. The purpose of the isolating switch is to isolate the power to the unit when ever a service or repair is carried out. It is therefore the manufacturers' recommendation that when ever the machine is tagged "out of service" that the tag be attached to the isolating switch via a padlock this will ensure that the machine will remain inactive and safe for the technician.
2. **Power In** - Power to the controller unit enters through the 3 phase power cable at the power in point. It is essential that the lead and plug be kept in good working order and free from possible damage and moisture entry. Note: all repairs to the electrical components must be carried out by those qualified to work with 3 phase power. If power at anytime becomes absent at the controller, (power light out), check the power entry system from the controller back to the main power source.
3. **Serial Number** - Every controller unit has its individual serial number. When ordering parts for the controller or the electrical system always quote the controller serial number as well as the baler serial number and date of manufacture.
4. **Ignition Switch** - The controller ignition switch has a security type key. If the baler is not in use or is in a public area it is advisable for the key to be removed. If additional keys are required these will need to be specially ordered from Farnells; from the baler manufacturer or the manufacturer's agent or representative.
5. **Emergency Stop Button** - The emergency stop button is fro emergency use. The emergency stop disables all electrical functions within the baler systems. To activate the emergency stop simply push the button firmly in. To release the emergency stop button to the active mode rotate the button clockwise until the button pops forward.
6. **Magnetic Door Switch** - The magnetic door switch is activated at the top of the upper door adjacent to the controller unit. One half of the magnetic switch is attached to the controller via plug socket (7) the other section of the switch is attached to the door. It is essential that these sections of the switch be correctly adjusted to each other. The two halves of the switch must never come into contact with each other or serious switch damage may occur. A correctly adjusted switch will have each section squarely situated to each other and will have a minimum of 1.5mm clearance to each other with a maximum clearance at any time of 4mm. More clearance than this will create a door open light to illuminate on the controller. During operation the movement in the top door may create a switch movement either apart of out of line with each other – this will depend on the machine and active the door open light. If switch adjustment is required adjust then carefully close the door ensuring that the two sections of the magnetic switch have the required clearance to prevent switch damage.

- 7. Door Magnetic Switch Plug** - This is the plug as described in (6) that is attached to the controller from the second half of the Magnetic Door Switch
- 8. Bale Counter** - The bale counter as the came suggests simply counts the number of bales being compacted. The bale counter performs an important function. Service intervals are time base or in situation of above average use are based on the number of bales completed. Refer to the Service Section of you Operators Manual for service intervals.
- 9. Eject** - The eject button activates the eject system removing the completed bale from the baler chamber. To operate the eject the bale must be complete with twines or fasteners secured, pressing fingers fully retracted, both doors fully open, and the bale transport trolley situated correctly in front of the bale to be ejected. The operator must stand to the side and safe from the passage of the ejecting bale. When ejecting the bale the eject button must be kept activated until the bale is fully ejected into the trolley.
- 10. Cycle Button** - The cycle button activates the cycle mode, when activated the baler arms will come down if in the retracted position. If the baler arms are down the baler will do a full cycle, i.e. arms up then back down. This should result in the system being "activated" the system active light will be illuminated. When materials are deposited into the baler chamber and the infra red beam emitting from the controller to the receiver on the rear wall is broken the baler will automatically start and do a full cycle, while ever the infrared beam remains broken the baler will continue to cycle until the beam is cleared of material.
- 11. Retract Button** - The purpose of the retract button is to raise the pressing arms to a vertical (out of the chamber position) and to remain there. This function is used when the bale is complete, tied off and ready to be ejected.
- 12. Power Boost Button** - The power boost button provision is used only after the full bale light and indicator has signalled a full bale. This button applies extra power to fully close the four main power hydraulic cylinders to give a constant bale size and length.
- 13. Full Bale Light and Siren** - When a full bale has been achieved the full bale light and siren will signal full bale. When these come on the automatic function feature of the baler will cease. The baler though can be manually operated to draw down surplus materials. A large piece of material can also at this point be placed in the chamber, the baler manually cycled to form a flat tidy top bale.
- 14. Power to Motor Port** - The power to motor port couples the motor and the controller together. The power socket can be removed by rotating the power to motor socket nut.
- 15. Polarity Change Port** - This port can be interchanged with the Power to Motor Port (14) to reverse the polarity of the motor. (Note motor must always rotate in a clockwise direction).
- 16. Thermo and Accessories Plug (*pug cap on spare port must always be attached!*)** - This port has the wiring to the thermo unit which detects overheated hydraulic oil and closes down the machine when the oil exceeds 60 degrees celsius. This will show on the door open light and also on the controller display as a overheat warning.
- 17. Warnings** - The bale counter display also doubles as a display screen showing various problem indicators i.e. pressure switch, overheating etc.
- 18. Connection Socket** - The connection socket contains the wiring looms from the controller to the following functions:
1. Solenoid valve to main compaction arms
 2. Solenoid valve to bale eject cylinder
 3. Pressure switch control wires
 4. Power boost wiring
 5. Full Bale switch
- 19. Light Indicator Grouping** - A series of vertical lights show the various functions of the baler:
- The up indicator light (top light) illuminates when the cycle button is activated and baler arms are rising.
 - The down light will illuminate when the baler direction is down.
 - The third light down (red is the power light. This light should illuminate when the key switch is turned on 2. The eject button is released and indicates power at the baler.
 - Door open light will indicate when the top door is open or the machine has developed a system fault such as an overheated system or pressure related problem.
 - The active light indicated that the baler system is active and will automatically start and cycle when materials break the infrared beam.
- 20. Warning** - Warning symbol indicates the presence of dangerous voltage within and is a warning to those qualified to ensure a power supply is disconnected before opening of the unit. To those who are not qualified to work with high voltage a warning not to open the unit with authorisation.
- 21. Fuse** - The controllers' electronic system is protected by a fuse. To access the fuse unscrew the fuse holder.
Fuse Type: 32mm glass fast blow fuse
Fuse Value: 4A

AUTOBALER

Bale Counter Safety Bar



TRAINER

MATERIAL

Customer: _____

Address: _____

Trainer: _____

Signature: _____

1. Controller Operation

1. power light on
2. Engage coded key bar – door open light on.
3. Disengage emergency stop key rotation
4. Cycle button to cycle
5. Retract button to raise fingers only
6. Red light and beeper full bale indicators


Turn the key on –



Trainer Signature of compliance:

2. Set Up


1. Remove the protective wrapping
2. Move all sundry items from within the baler
3. When moving or relocating the baler carefully follow the lifting instruction and safety procedure.



Trainer Signature of compliance:

3. *Baler Fit Out*


1. Fit the mesh hopper above the baler
2. Position the twine cage to the side of the baler
3. Situate the baler removal and storage trolley
4. Fit canopy to balers with auto cycle provisions



Trainer Signature of compliance:

4. Initial Set


1. Turn the controller key on
2. Press retract button – check motor rotation for clockwise direction – stand fingers up and clear of the bale chamber
3. Check that twine roll is correct side up – draw twine and cut to length as on the illustration below (all three twines are the same length)



Trainer Signature of compliance:

5. Tying the Loop


1. Tie the double loop in twine ends.
2. Open all doors
3. Attach the outer loops of the twine to the left hand side of the baler
4. Down to tab on left side then across the floor then under the tab on the right hand side.
5. Rotate the twine end around the eye bolt twice then tie off with one loop
6. Repeat his process on all three twines



Trainer Signature of compliance:

6. Transverse Twining

1. Hook twine loop or domed hook on rear will of baler
2. Position twine under rear twine tab on the baler floor
3. Position twine under front floor tab
4. Close bottom door and bring twine up the inside of the front door and over the top and fix twine end to twine tab by rotating once then fixing the twine in the tab slot.




Trainer Signature of compliance:

7.

Initial Fill


1. Fill the lower section of the baler chamber with the top door open. (*note pressing fingers need to be fully retracted*)
2. When the lower section is full close the top door and deposit materials over the top door until visible.
3. Activate the cycle button
4. Cycling the baler with o material or insufficient materials will cause a loud bump.



Trainer Signature of compliance:

8. Baler Operation


1. T1100 & T1200 balers have automatic function.
2. Button or automatic activation is required for each cycle.
3. Peddle (or foot activation is optional) on T1100 & T1200 units



Trainer Signature of compliance:

9. **Tidy Bale Procedure**


1. Last 10% of the bale, flattened material laid flat
2. When full bale light comes on:
 - i. Remove excess material by cycling manually by pressing the cycle button (several cycles may be required)
 - ii. For neat top, place large flattened material on the top of the bale and activate cycle button.



Trainer Signature of compliance:

10. Tying Off


1. Open the top door
2. Remove loose or protruding materials from above the fingers
3. Unhook the twines on the looped ends (*cut upper loop if too tight and use lower loop to tie off*)
4. Untie plain twine end and insert through the loop. Pull tight and tie off securely.



Trainer Signature of compliance:

11. Transverse Twine Tie Off


1. Unhook from rear baler wall.
2. Release plain end from the tab on the outer front lower door.
3. Pass the plain end through the looped end. Pull tight and tie off securely



Trainer Signature of compliance:

12. Retracting Fingers


1. Close top door
2. Turn power on
3. Press retract button (hold button until the fingers are fully retracted)



Trainer Signature of compliance:

13. Opening the doors


1. Open the top door (beware of possible rebound)
2. Open the bottom door (beware of possible rebound)
3. Open the bottom door fully
4. Insert the bale removal trolley tines into slots in the baler floor or with auto eject models position the bale transport trolley for ejection onto the trolley.
5. When fully inserted gently pull back on trolley handle and wheel away for storage.
6. Note do not open the bottom door with the fingers down.



Trainer Signature of compliance:

14. Bale removal and storage safety procedure

1. Ensure that the person removing the bale is of sufficient strength and fitness to prevent personal injury.
2. Heavier bales may require a three wheeled trolley, supplied as an option at the customers request.
3. Beware of over balance and possible back or foot injury.



Trainer Signature of compliance:

Autobaler Trainee Particulars (Kit)

Company: _____

Address: _____

Trainee Name: _____
(Print Clearly in Capitals)

Address: _____

Phone No: _____

Employer: _____

Date Of Training: _____

Autobaler Model Trained To Use: _____

I, _____ (Trainer) witnessed the competency of
_____ In the safe competent use of the Autobaler Model
_____ and I received a copy of the Training Manual.

I hereby validate this assessment.

Signed (Trainer): _____

Date _____

Signed (Trainee) _____

Date _____

Special Comments _____

Trainee Exam Questions (Autobaler TI100/TI200 Series)

1. If the baler is in a public access area and the baler will be unattended for a long period, what precaution for public safety should you take:
 - a. Sit and watch the baler.....
 - b. Remove the key.....
 - c. Do nothing.....

2. What function does the retract button have:
 - a. General operation.....
 - b. Cycles the baler.....
 - c. Raises the fingers only.....

3. The purpose of the safety bar is:
 - a. To do chin ups.....
 - b. For emergency stopping.....
 - c. No particular use.....

4. When twining the baler at what position should the baler fingers be:
 - a. Right down.....
 - b. Half way down.....
 - c. Fully up.....

5. What is the purpose of the plastic tabs on the base (floor) of the baler:
 - a. Decoration.....
 - b. Place twine beneath.....
 - c. Structural.....

6. The last 10 - 20% of the bale, how would you place flattened material:
 - a. On its edge.....
 - b. Anyway.....
 - c. Flat in the baler.....

7. Tying of the finished bale should be done with the:
 - a. Fingers up (retracted).....
 - b. Fingers half way.....
 - c. Fingers right down.....

8. Opening of the top door, I should:
 - a. Open it the best I can.....
 - b. It doesn't matter.....
 - c. Grip the handle firmly.....

10. Ejecting the bale, I should:
- a. Pull as hard as I can on the twine.....
 - b. Place the eject trolley in front of the baler with all doors open and in a roll away from the baler position.....
 - c. the best I can.....
11. Where should the bale transport trolley be stored when not in use:
- a. Under the right hand side.....
 - b. Under the left hand side.....
 - c. Anywhere.....
12. Real heavy objects i.e. boxes of magazines etc. How should I load them into the baler:
- a. Over the top door.....
 - b. Open the top door.....
 - c. The best I can.....
13. If the baler operates with the top door open, I must:
- a. Continue as normal.....
 - b. Shut the machine off, remove the key and place out of order sign.....
 - c. Take care.....
14. Was the knot test passed? Yes No

CHAPTER 6

MAINTENANCE & CLEANING SECTION

Always disconnect Electrical Supply before Changing Any Equipment!

A. MAINTENANCE DEFINITION

Standard Maintenance:- A service provided at four monthly.

Average usage:- A baler producing up to 5 bales per day - recommended preventative maintenance period not to exceed four months and to be serviced according to the standard servicing schedule.

High usage:- a baler producing more than five bales per day - recommended service period not to exceed four months and to be serviced according to the standard servicing schedule.

Major Maintenance:- A serviced preformed every 12 months or every 660 bales and to be serviced according to the standard servicing schedule. A major service has the additional service elements.

1. Oil filter change
2. Hydraulic oil test and changed if required
3. Finger lock spring change
4. Main cylinder pivot pin check for wear or fatigue

B. WEEKLY MAINTENANCE CHECK

- a. Check safety guards around moving parts. Are they in place? Are they damaged?
- b. Check Autobaler key switch, is it functional and in good order?
- c. Check emergency stop button, is it functional and in good order?
- d. Check safety bar, is it functional and in good order?
- e. Check power lead, is it undamaged? Is it clear of any moisture?
- f. Check Autobaler response to opening top door. Opening more than 50mm (approx 2 inches) should cause the machine to cease cycling.

If any of the above checks reveal damage or malfunction, the machine should be shut down and the key removed until the fault is repaired

C. PREVENTATIVE MAINTENANCE:

- a. Every 4 months, or every 500 bales, the operation of the Autobaler should be checked by a qualified person to ensure that all safety features are functioning correctly and are undamaged.
- b. From time to time, a qualified electrician should inspect all power leads and electrical contacts.

D. MACHINE CLEANING:

To keep your Autobaler in top working condition, frequent cleaning is required.

Power Unit:

Never attempt to service the power unit without first thoroughly cleaning the unit.

- Remove the retainer screws holding the hinged mesh covers
- Note: Always disconnect the power socket from the power source plug before attempting any guard removal
- Remove the key from the controller and attach an 'in service' note to the baler
- Keeping the power unit clean will prevent overheating and system contamination

NOTE: - *Power unit must be cleared of accumulated material pieces on a regular basis to prevent overheating.*

Cylinder enclosures:

As with the power unit service, totally isolate the power, remove the key and fix an 'in service' sign.

- Undo screws and remove side meshes to give good access to both sides. Clean all loose materials from this area of the machine. Often materials become compacted behind the hydraulic cylinders adding additional strain to the machine (remove these materials)
- This should be done at least every monthly depending on the use of the baler

Baler Chamber:

Using a soft cloth, clean the outside of the machine to keep it in good appearance. Never use petrol or mineral solvents to clean the machine as this may damage the paint.

E. GENERAL HOUSE KEEPING

Daily remove material build up around the baler, especially between the rear of the baler and the wall. A material build up creates a fire and vermin hazard. Keep the access area to the baler free of all materials to prevent a trip hazard and other OH&S concerns.

F. SERVICE INTERVALS

- i. Autobalers require regular maintenance intervals to ensure that they perform and operate safely, reliably and efficiently.
- ii. Autobalers must be serviced by qualified service people who have been instructed in the service of Autobalers
- iii. Autobalers must be serviced according to the service requirements as laid out in the maintenance manual supplied with each Autobaler.
- iv. It is a requirement that when an Autobaler has an interval service that the appropriate service leaf be dated and filled out according to the service and signed by the service technician.

- v. It is recommended that a service interval not exceed 4 months or every 500 bales. Autobalers must be serviced within this period during the warranty period.
- vi. An integral component of the service is a comprehensive safety check to ensure interlocks and all other safety devices and guards are in good safe working order.

G. RECOMMENDED LUBRICANTS

- i. Recommended hydraulic oil *AWH 32 Castrol*
- ii. Autobalers have high pressure pivot points which require high pressure grease, therefore it is recommended that only Pro-ma MBL grease be used in the service of Autobalers or a grease with equivalent lubrication properties (see data sheet). If maintenance periods are exceeded or lubricants used which are outside the manufacturers recommendations, Autobaler warranty may be voided.

H. DATA SHEET, PRO-MA MBL 8 GREASE

Benefits Of Use

1. Performs within high and low temperature operating ranges
2. Resists water and water washout
3. Provides oxidation stability
4. Protects against rust
5. Protects against extreme pressure
6. Works well with high loading or severe shock loading
7. Extends lubrication periods
8. Prevents excessive seal swelling

The Base Grease Used in MBL Grease has the Following Specifications

NLGI Grade.....2
 Soap Type.....Lithium-Complex
 Texture.....Buttery

Base oil viscosity

CST at 40°C.....148
 CST at 100°C.....14
 SUS at 100°F.....767
 SUS at 210°F.....75
 Base oil viscosity index.....90
 Dropping point C (F) (ASTM D 2265).....280° + C (500° + F)

Penetration, mm/10 (ASTM D 217)

Unworked.....280
 Worked 60 Strokes.....285
 Worked 100,000 strokes, % change.....+ 10

Trident probe viscosity (ASTM D 3232)

204°C (400°F), poises.....15

Oil Separation (ASTM D 1742)

24 hr at 25°C (77°F), %.....3

Lubrication life (ASTM D 3336), no.204 bearing

10,000 rpm, 163°C (325°F), hrs.....290

Oxidation stability (ASTM D 942)

Pressure drop at 100hr, kPa (psi).....14 (2)
 Pressure drop at 500hr, kPa (psi).....70 (10)
 Roll stability (ASTM D 1831) % penetration change.....+ 10

Wheel bearing test (ASTM D 1263 modified:60-9 pack 160°C (325°F)

Leakage, g.....1.5

Load carrying properties:

Timken load (ASTM D 2509,kg (lb).....25 (55)

4-Ball EP test (ASTM D 2596)

Load wear Index, kg.....40
 Weld point, kg.....250

4-Ball wear test (ASTM D 2266), 40 kg 1200rpm,

75°C (167°F), 1 hr. Wear scar diameter, mm.....0.40

Ball-joint test (ASTM D 3428)

Brine sensitivity (noise and wear).....Pass
 Torque stability.....Pass
 Water washout (ASTM D 1264), % at 80°C (175°F)......4
 Rust prevention (ASTM D 1743), ASTM rating......1

Low temperature torque (ASTM D 1478), -40°C (-40°F)
Starting, g-cm.....13,000Running,
g-cm.....5,000

Mobility (U.S. Steel method)

Flow rate at -18°C (0°F), g/sec.....0.5

Rubber swell (GM method) 70hr at 100°C (210°F)

Volume change, %.....+ 12

Handling

Product contains petroleum oil, copper and lead particles, **Do NOT store near heat, sparks or flame.** Wash with soap and water after contact with skin. KEEP OUT OF REACH OF CHILDREN. A material Safety Sheet is available from Pro-Ma Systems.

Warning

Do NOT take internally. **Harmful or fatal if swallowed.** Contains copper and lead particles and hydrocarbons. If swallowed contact a doctor immediately. Wash hands after use.

Medical advice

Contains petroleum oil, copper and lead particles. **If swallowed, do NOT induce vomiting.** Call physician immediately.

Available Sizes

450g, 2.5kg, 20kg, 60kg, and 202.5kg.

3. Material Safety Data Sheet

Product Name: **SUPERDRAULIC RANGE**

Date Issued: 3 June 1997

IDENTIFICATION

Use: General purpose hydraulic oil.

Not classified as hazardous according to criteria of Worksafe Australia.

Company: WESTERN OIL
1 COOMBES DR
PENRITH

UN No. : **Not Assigned**
Main Class : **Not Assigned**
Subsidiary Risk : **Not Assigned**
Poisons Schedule : **Not Allocated**
Hazchem Code : **Not Assigned**
CAS No. : **Not Relevant**

PRODUCT PROPERTIES

Appearance & Odour : **Clear and bright oily liquid. Mineral oil odour.**

Chemical Reactivity: **Stable. Reacts with oxidising agents.**

Solubility in Water: **Negligible**

Property	Value	UOM	Temp
Specific Gravity	0.87	-	15
Melting Point	Not Available		
Vapour Pressure	Expect<0.0005	kPa	20
IBP	Typically 280	deg C	
FEP	Not Available		
Evaporation Rate	Not Available		
Vap Dens (Air=1)			>1 -
Fire/Explosion Hazard			
Flash Point	Typically>224	deg C	
Autoignition	Typically>320	deg C	
% Volatiles	Not Available		
LEL	Expected 1	%v/v	
UEL	Typically 10	%v/v	

PRODUCT INGREDIENTS

Blending Ingredient	Proportion	Method	CAS No.
Highly refined mineral oil	High >99.4%	m/m	
Complex mixture of additives	Low < 0.6%	m/m	

HEALTH HAZARDS

HEALTH EFFECTS

Acute

Swallowed

Slightly toxic, may cause gastric irritation

Eye

Product may cause slight to moderate irritation to the eyes.

Skin

Mildly irritating to skin. Prolonged and repeated skin contact may cause dermatitis due to defatting effect.

Inhaled

Inhalation of the vapours (generated at elevated temperatures) or mists can cause irritation to the nose and throat.

FIRST AID

Swallowed

If swallowed, do NOT induce vomiting, seek medical advice.

Eye

Flood eyes with plenty of water for 20 minutes. If irritation occurs seek medical advice.

Skin

Remove contaminated clothing and wash skin thoroughly with soap and water.

Inhaled

Remove affected person from contaminated area and seek medical advice. If not breathing apply artificial respiration and seek urgent medical advice.

Advice to Doctor

PRECAUTIONS FOR USE

Exposure Standards

Worksafe Exposure Standard :- time weighted average (TWA) 5 mg/m³ (oil mist) short term exposure limit (STEL) 10mg/m³ (oil mist)

Engineering Controls

Special ventilation is not normally required due to the low volatility of the product at normal temperatures. However, in the operation of certain equipment or at elevated temperatures, mists or vapour may be generated and exhaust ventilation should be provided to maintain airborne concentration levels below the exposure standard or where no exposure standard is allocated, as low as is reasonably practicable.

Personal Protection

Avoid contact with the skin and eyes, and avoid breathing vapours or mists. When exposure is likely, personal protective equipment in a combination appropriate to the degree and nature of exposure, should be selected from the following list:-

- (1) Eye protection
- (2) PVC gloves
- (3) PVC apron and sleeves, or full PVC covering
- (4) PVC or rubber boots

Where the concentration of vapour or mist is expected to approach the exposure limit, the following additional equipment is recommended:-

- (1) Short elevated exposures, eg spillage - goggles and correct respiratory protection should be worn.
NB. If the vapour/mist concentrations exceed the exposure limit by more than 10 times, air supplied apparatus should be used.
- (2) For prolonged elevated exposures - Full face air supplied or self contained breathing apparatus should be worn.

CONTAMINATION

If contamination occurs, change clothing and discard internally contaminated gloves and footwear. Launder contaminated clothing before reuse.

Observe good personal hygiene.

Eye wash fountains and safety showers should be available for emergency use.

REFERENCES

For detailed advice on Personal Protective equipment, refer to the following Australian Standards

HB 9 (Handbook 9)	Manual of industrial personal protection.
AS 1337	Eye protectors for industrial applications.
AS 1715	Selection, use and maintenance of respiratory protective devices.
AS 1716	Respiratory protective devices.

Flammability

Combustible liquid, will not burn unless preheated

Refer to AS 1940 - Storage and handling of flammable and combustible liquids and AS 2865 - Safe working in a confined space, for more specific information on these subjects.

SAFE HANDLING INFORMATION

Storage & Transport

Classified as a class C2 combustible liquid for storage and handling purposes. Store in a well ventilated place away from ignition sources, oxidizing agents foodstuffs and clothing. Keep containers closed when not in use.

Spills & Disposal

Extinguish or remove all sources of ignition and stop leak if safe to do so. Contain the spill with sand or earth and take up with a vacuum truck or absorb with absorbent material, sand or earth. Place used absorbent in suitable sealed containers and follow state or local authority regulations and guidelines for disposal of the waste. Clean area with detergent and water. Do not allow product to enter drains, sewers or water courses inform the local authorities if this occurs.

Fire/Explosion Hazard

Combustible. Combustion products include oxides of carbon. Keep storage tanks, pipelines, fire exposed surfaces etc cool with water spray. Shut off any leak if safe to do so and remove sources of re-ignition. Use foam, CO2 or powder to extinguish fire.

OTHER INFORMATION

Long term animal experiments have shown that any health risks are associated with the level of aromatic and polycyclic constituents in the product. These constituents are removed during the manufacturing process to a level at which no health risks are expected as a result of normal handling.


CONTACT POINT

Emergency Response :- 02 4732 3305

*** END ***

CHAPTER 7

REV#	DATE	REVISED BY	NOTES
A	24/10/06	DPH	PRELIMINARY REVISION




PLAN VIEW

THIS DRAWING IS THE PRIVATE PROPERTY OF TRETHEWEY INDUSTRIES PTY LIMITED AND WITHOUT THEIR CONSENT MUST UNDER NO CIRCUMSTANCES BE SHOWN OR GIVEN TO ANY COMPETITORS OR THIRD PARTIES.
ALL LEGAL RIGHTS RESERVED.

<p>Trethewey Industries PTY LTD 15/4 ENDING HWY DEPOTTS PO BOX 4716 WAVERLEY VIC 3024 email: trethewey@trethewey.com.au</p>		<p>FACILITY ARRANGEMENT</p> <p>AUTOBALER SL 200 FACILITY DRAWING 1/2</p>	
		<p>DATE: 24/10/06</p> <p>BY: DPH</p>	<p>DATE: 24/10/06</p> <p>BY: DPH</p>

REV#	DATE	REVISED BY	NOTES
1			



FRONT ELEVATION

THIS DRAWING IS THE PRIVATE PROPERTY OF TRETHEWEY INDUSTRIES PTY LIMITED AND WITHOUT THEIR CONSENT MUST UNDER NO CIRCUMSTANCES BE SHOWN OR GIVEN TO ANY COMPETITORS OR THIRD PARTIES.
ALL LEGAL RIGHTS RESERVED.



FACILITY ARRANGEMENT

<p>Trethewey Industries PTY LTD NEW ENGLAND HCY REGISTRATION Ph: 083 479 5443 Fax: 083 479 5433 email: trethewey@trethewey.com.au</p>	<p>AUTOBALER SL 200</p>		<p>FACILITY DRAWING 232</p> <p>DRAWING NUMBER/FACILITY</p> <p>ISS: -</p> <p>DATE: -</p> <p>xSL100-FAC-S002</p>	<p>REVISION</p> <p>A</p>
	<p>ISS: -</p> <p>DATE: -</p>	<p>ISS: -</p> <p>DATE: -</p>		