



SPARE PARTS LIST FOR BALER CONTROLLERS



Controllers with serial numbers beginning with 901672....
Manufactured prior to 2001.
Limited field serviceability - PCB's can not be field exchanged.



Controllers with serial numbers beginning with SL.
Serial number coding scheme:
SLMMYY-NN
where:
MM= month of manufacture
YY=year of manufacture
NN=unit no. in that month
From serial number SL0903-05 onwards all units are category III safety compliant.



Controllers with serial numbers beginning with CS.
Serial number coding scheme:
CSMMYY-NN
where:
MM=month of manufacture
YY=year of manufacture
NN=unit no. in that month
From 2007 onwards these units will be modified to control balers with phasing cylinders fitted.


**Contact Trethewey Industries for ALL spare parts purchases on:
Ph: 1800-888-403 Fax: (02) 6734-5433
www.autobaler.com**

Purchases contact: Ph 1800-888-403 Fax (02) 6734-5433




Spare circuit board module for controllers with serial numbers beginning with the letters CS. See the CybaSMART service manual for replacement procedure.

Order Code: CS-PCB



Spare touch pad for controllers with serial numbers beginning with the letters CS. See the CybaSMART service manual for replacement procedure. **DO NOT BEND TOUCH PAD.**

Order Code: CS-TP1



Spare circuit board module for controllers with serial numbers beginning with the letters SL. See the PressMate service manual for replacement procedure.

Order Code: SL-PCB



Spare touch pad for controllers with serial numbers beginning with the letters SL. See the PressMate service manual for replacement procedure. **DO NOT BEND TOUCH PAD.**

Order Code: E-ov



Spare full bale switch for all controllers with serial numbers beginning with SL and all controllers with serial numbers beginning with CS manufactured before 2007.

Order Code: CS-FS (or Omron Z15GQ21B)



Spare key switch plus two keys for controllers with serial numbers beginning with SL or CS. No contact blocks supplied with the switch.

Order Code: CS-KS (or GE P9XSCD0A95)



Spare key pair for all controllers with serial numbers beginning with SL or CS. Note: all controllers keyed alike.

Order Code: CS-SK (or GE 077C3095)

Purchases contact: Ph 1800-888-403 Fax (02) 6734-5433



Spare magnetic top door switch for all controllers with serial numbers beginning with CS. (Note: plug only fitted to part supplied by StarLogixs.)

Order Code: CS-DS (or Omron D40DB-1B3)



Spare eye transmitter unit for all controller models. This is the unit mounted on the back of the baler.

Order Code: CS-IR



Tapered eye block . Used to mount eye transmitter on later model controllers with serial numbers beginning in SL and all controllers with serial numbers beginning in CS.

Order Code: CS-B



Eye cover box. Used on all model controllers to cover the eye transmitter unit on the rear of the baler.

Order Code: CS-Box



Thermal switch (mounts on hydraulic manifold block). For controllers with serial numbers beginning with SL:
Order Code: SL-TS (N/C Type)

For controllers with serial numbers beginning with CS:
Order Code: CS-TS (N/O Type)



Spare 4A x 32mm fuses. Used in all models of controllers.

Order Code: CS-FUSE



Spare contact blocks, used on all controller models. Normally open type:

Order Code: CS-CB0 (or GE part P9B10VN)

Normally closed type:

Order Code: CS-CB1 (or GE part P9B01VN)

Purchases contact: Ph 1800-888-403 Fax (02) 6734-5433



Spare full bale beeper. Used on all controllers with serial numbers beginning with SL or CS.
Order Code: CS-BEEP (or Kingstate KPE657)



Mains power transformer used in all controllers with serial numbers beginning with SL or CS.
Order Code: CS-TR1



Panel fuse holder, used on all controllers.
Order Code: CS-FH1



Three pole motor contactor.
Order Code: CS-CNTCT(4kW) or GE Part CL00A310TD
Order Code: CS-CNTCT(5.5kW) or GE Part CL01A310TD




Motor overload relay.
Order Code: CS-OR(4kW) or GE Part RT1N
Order Code: CS-OR(5.5kW) or GE Part RT1P



Full bale switch used on controllers with serial numbers beginning with CS and supplied from 2007 on-wards.
Order Code: CS-FSL (or NAIS part NAZD1004)



Spare key switch for controllers with serial numbers beginning with 901672....
Order Code: 901KeySw



Spare keys for controllers with serial numbers beginning with 901672....
Order Code: 901Key



Motor socket, used on all controllers with serial numbers beginning in SL or CS.
Order Code: CS-MS



Motor socket cap, used on all controllers with serial numbers beginning in CS.
Order Code: CS-CAP




Full bale lamp, used on all controllers with serial numbers beginning with SL or 901672....
Order Code: 128-85890 Narva

Purchases contact: Ph 1800-888-403 Fax (02) 6734-5433




Full bale lamp bulbs (24V 3W), used in all controllers with serial numbers beginning with SL or 901672...
Order Code: 47368 Narva



Interlocked door switch, used on all controllers with serial numbers beginning with SL.

Order Code: D4DS-1AFS Omron



Interlocked door switch key, used on all controllers with serial numbers beginning with SL.

Order Code: D4DS-K1



9 pin backshell kit, used on all controllers with serial numbers beginning with SL.

Order Code: SL-D9



15 pin backshell kit, used on all controllers with serial numbers beginning with SL and CS.

Order Code: CS-D15



25 pin backshell kit, used on any controller with serial numbers beginning with CS and using the options plug.

Order Code: CS-D25



Motor cable, used on all controllers with serial numbers beginning with SL or CS.

Order Code: CS-MC